

Instructions for installing Model 3400 Quail Rails in the Model 3200 Automatic Egg Turner

WARNING: This is an indoor electrical product that requires basic safety precautions to minimize the risk of electrical shock, personal injury, and product damage. Read all directions and precautions carefully before putting into operation.

When using electrical products, safety precautions must be followed as described below:

- 1. Read all instructions.
- 2. To protect against electrical hazards, **DO NOT IMMERSE THE PRODUCT IN WATER WHEN MOTOR IS ATTACHED!**
- 3. Always unplug the product when not in use.
- 4. Do not use extension cords!
- 5. **Do not use the product** if the product has malfunctioned or has been damaged in any manner.

Instruction for installing Model 3400 Quail Rails:

- 1. Place Automatic Egg Turner on flat surface with motor facing upwards. Slide cord out of slot on plastic side arm. Remove the two screws holding the motor in place (Figure "A"). Lift out motor.
- 2. Rotate plastic side arm so that regular egg trays are in vertical position (Figure "B"). Lift up to remove.
- 3. Install Quail Rail trays into slots on plastic side arm. (Figure "C")
- 4. Rotate plastic side arm so that trays are in horizontal position. (Figure "D")
- 5. Re-install motor and slide cord back into the slot. (Figure "D")









Figure A

Figure B

Figure C

Figure D

If you have any questions, please call customer service at 800-277-8401.