WARNING: This is an outdoor product that requires basic safety precautions to minimize the risk of electrical shock, personal injury, and product damage. Read all directions and precautions carefully before putting into operation. Use on flat hard surface. **DO NOT USE ON CARPET, HAY, OR FURNITURE!!** 

## MODEL HM-60P HEATED CHICKEN MAT. READ ALL INSTRUCTIONS!

When using electrical appliances, safety precautions must be followed as described below:

- 1. Read all instructions.
- 2. To protect against electrical hazards, DO NOT IMMERSE THE PRODUCT IN WATER!
- 3. Close supervision is necessary when using by or around children.
- 4. Always unplug the product when not in use or when cleaning.
- 5. **Do not use the product** when obvious damage is noticed to the supply cord or plug. Inspect cord before using.
- 6. **Do not use the product** if the product has malfunctioned or has been damaged in any manner.
- 7. **Do not dismantle or puncture the mat for any reason.** This could cause damage and will void the warranty.
- 8. **Do not cover the product** with blankets or other material as this will affect the performance and effectiveness of the product that may cause the product to fail.
- 9. **Do not use or place on furniture or carpet.** Intended to be placed on hard flat surface inside coop, hutch, or pen. Be sure that mat covers no more than half of the floor space so your chickens can sleep either on or off of the mat.

## **Instruction for use: 120 VAC only**

- 1. Place the Heated Chicken Mat directly on a **hard flat surface** inside a coop or pen. Area should be out of direct sun, rain, or snow. Product may be mounted by drilling holes and using screws (not included) to mount in the outer lip portion of the pad only. Do not puncture or drill holes in any part of the main sleeping surface of the mat.
- 2. Plug the product directly into a 110/120 volt GFCI A/C outlet. Allow one hour for the unit to warm to temperature the LED light will indicate the unit is on. The product may feel slightly warm depending on ambient temperature. Once the animal lies on the mat it will reach its pre-set temperature. Your chicken's body temperature will help hold the mats pre-set temperature.
- 3. Unplug, clean, and store when not in use. Product can be cleaned with damp cloth or sponge. Dry thoroughly before plugging back in.
- 4. Store indoors after winter season. Inspect cord before using. Read all instructions.
- 5. Do not use extension cords.

## **Test for proper operation:** This mat will not feel warm to the touch when used in cold climates.

(1) Check the LED indicator light for operation. (2) Place a large heavy object (phone book) on the mat to cover over 1/3 of the surface area. Remove the large object after 30 minutes to test for contained heat underneath the object. If the surface is warm to the touch <u>immediately</u> after removing the large object then the Heated Chicken Mat is operating properly. We hope your chickens enjoy the warmth during the winter!

If you have any questions, please call customer service at 800-277-8401.

## **Limited Warranty**

The Heated Chicken Mat, Model HM-60P is guaranteed for one year after the original date of consumer purchase or date stamped on the unit against defects due to material and the company's workmanship only. The sole obligation shall be to replace the defective unit with a replacement unit. Units should be "Checked for proper operation" prior to returning as defective. Units must be returned prepaid. No liability for loss or damage of any nature or kind, whether arising out of or from the use of the product, whether defective or not defective, is assumed by Farm Innovators, Incorporated.

Return address: Farm Innovators, Inc. 2255 Walter Glaub Drive, Plymouth, IN 46563.